

# LAYOUT

## CONCEPTS

### Reversing Loop Using Cobalt iP Analog Motor & REX & ADiA & Magnetic Sensors

Make sure this distance leaves enough time for the point to change before the train reaches the point.

General Note:  
The reversing loop must be longer than the longest train to use it.

