

LAYOUT

CONCEPTS

iP-CB Intelligent Circuit Breaker Manual Reset Switch & LED Indication

IMPORTANT
Always set the iP-CB trip current with the header to be **LOWER** than the main system maximum current output.

