

LAYOUT

CONCEPTS

Reversing Loop With Cobalt iP Digital Motor & Cobalt Rex

Notes for setup:

- Step 1 - Set the frog polarity - if it is the wrong way round reverse, the connection on the point motor, DCC In.
- Step 2 - Set the loop polarity, swap connections X1 and X2 if required - see middle right on diagram.

General Note:
The reversing loop must be longer than the longest train to use it.

