

# LAYOUT

## CONCEPTS

### Cobalt iP Digital Point Motors Controlling An Asymmetrical 3-Way Point From An Accessory Bus

When wiring a cascade of frogs, i.e. a ladder of points, check the correct polarity on FROG 1 before wiring FROG 2 etc. If you don't and a frog is wired incorrectly, it will be difficult to identify.

The orientation of the Cobalt point motors will affect the wiring. If the frog shorts, change the **S2-L** and **S2-R** wires over.

