

# LAYOUT

## CONCEPTS

### Cobalt iP Digital Point Motors Controlling An Asymmetrical 3-Way Point

If the point frog shorts, swap the **DCC IN** wires over.

When wiring a 'cascade' of frogs, i.e. a ladder of points, check the correct polarity on FROG 1 before wiring the next FROG, or it may be difficult to identify the incorrect frog wiring.

